UNDER COVER PADDING INSTRUCTIONS

- 1. Install LOOP-LOC Cover according to installation instructions.
- 2. Lay the undercover padding on top of the cover, at the covers edge.
- 3. With a marker or crayon, mark location of each strap on the padding.
- 4. **IMPORTANT**: Remove the padding completely off the cover before proceeding to step # 5
- 5. using a utility knife cut 2 1/2" wide slots, 3/4" down from the top of the padding hem, at the strap locations mark in step 2. (see illustration #1)
- 6. The padding section is now ready to be installed under the cover . Detach springs from the anchors and slide the padding section under the cover , hem side up.
- 7. Thread the spring and the strap through the slotted padding , and re attach to the anchors . (see illustration # 2)

HELPFUL HINT:

** Working in sections, detach spring from anchors and install padding. Re - attach springs and repeat procedure for each additional area requiring padding.

